

Manıtowoc

Grove Manitowoc National Crane Potain

## **Grove RT890E** Product Guide



### **Features**

- 80 t (90 USt) capacity
- 11,4 m 43,2 m (38 ft 142 ft) five-section, full power boom
- 10 m 17 m (33 ft 56 ft) offsettable bi-fold lattice, swingaway extension
- 4,8 m (16 ft) or 9,7 m (32 ft) extension inserts
- Grove MEGAFORM™ boom
- 9979 kg (22,000 lb) counterweight hydraulically installed and removed




## Features

#### Removable counterweight

Counterweight and auxiliary hoist is hydraulically removed/installed for easier hauling from job to job.





#### Power luffing extension

For improved up-and-over reach, a power luffing extension is available on the RT890E and hydraulically offsets from the super-structure cab from 5° to 40°.



The Full Vision cab on the RT890E tilts up to 20° providing the operator additional comfort when working at long boom and extension lengths.



CraneSTAR is an exclusive and innovative crane asset management system that helps improve your profitability and reduce costs by remotely monitoring critical crane data. Visit www.cranestar.com for more information.



#### Boom

The RT890E is equipped with a 11,4 m - 43,2 m (38 ft - 142 ft) five-section, full power boom. The Grove MEGAFORM<sup>™</sup> boom shape eliminates weight and increases capacity compared to conventional shapes.



## Contents

Features	2	
Specifications	4	
Dimensions and weights	7	
Working range	8	
Mode A vs. (Mode B)	9	
Load chart (Mode B)	10	
Load chart fixed offsettable swingaway	11	
Working range with one 16 ft insert	12	
Working range with two 16 ft inserts	13	
Load charts fixed offsettable swingaway with inserts	14	
Load charts (Mode A)	15	
Luffing extension charts	17	
Load handling	21	

#### CURRAN C F A D E ITS NOT LUCK, ITS KNOW

## Specifications

Superstructure (continued)

#### Hoist specifications (HP30-18G) main and auxiliary hoist

Planetary reduction with automatic spring applied multi-disc wet brake. Electronic hoist drum rotation indicators, and hoist drum cable followers.

Maximum single line pull:

1st layer: 9185 kg (20,250 lb) 3rd layer: 7715 kg (17,010 lb) 5th layer: 6650 kg (14,660 lb)

Maximum permissible line pull: 7620 kg (16,800 lb) with 35x7 class rope

Maximum single line speed: 156 m/min (514 fpm)

Rope construction:

35x7 rotation resistant

Rope diameter: 19 mm (3/4 in)

Rope length:

Main hoist: 182 m (600 ft)

Auxiliary hoist: 182 m (600 ft)

Maximum rope stowage: 256 m (841 ft)

#### Carrier



Box section frame fabricated from high-strength, low alloy steel. Front/rear towing and tie down lugs.

#### Outrigger system

Four hydraulic telescoping single-stage double box beam outriggers with inverted jacks and integral holding valves. Three position setting, 0%, 50% and fully extended. Outrigger monitoring comes standard.

All steel fabricated, quick release type outrigger floats, 775 mm (30.5 in) diameter.

Maximum outrigger pad load: 56 700 kg (125,000 lb).

#### Hydraulic system

Two main pumps ([1] piston and [1] gear) with a combined capacity of 503 LPM (133 GPM).

Maximum operating pressure: 277.7 bar (4000 psi).

Three section pressure compensated valve bank. Return line type filter with full flow by-pass protection and service indicator. Replaceable cartridge with micron filtration rating of 5/12/16. 959 L (253 gallon) hyd. reservoir. Carrier mounted oil cooler with thermostatically controlled hydraulic motor driven fan/air to oil. System pressure test ports.

#### Outrigger controls

Controls and crane level indicator located in cab.



#### Engine (Tier IVF)

Cummins QSB 6.7L diesel, six-cylinder, turbo-charged. 205 kW (275 hp) at 2500 rpm.

Meets emissions per U.S. E.P.A., Tier IV Final and E.U. Stage IV.

Maximum torque: 987 Nm (728 ft/lb) at 1500 rpm.

Fuel requirement: Minimum of 15 ppm sulphur content (Ultra Low Sulphur Diesel Fuel and Diesel Exhaust Fluid (DEF))

Note: Tier IVF engine required in North American, Canadian, and European Union countries.



#### Engine (Tier III)


Cummins QSB 6.7 L diesel, six cylinders, turbo-charged, 205 kW (275 bhp) (Gross) at 2500 rpm.

Maximum torque: 987 Nm (728 ft/lb) at 1500 rpm. Note: Required for sale outside of North American and European Union countries.



#### Fuel tank capacity

280 L (74 gal)



Full rangeshift with 6 forward and 6 reverse speeds. Front axle disconnect for 4 x 2 travel.

### Electrical system

Three 12 V - maintenance free batteries. 12 V starting and lighting. Battery disconnect. CanBus Diagnostic system.



5767 (supersedes 5721)-0117-N4



## Specifications

#### Carrier (continued)

4 x 4.

Steering

Fully independent power steering:

Front: Full hydraulic steering wheel controlled.

Rear: Full hydraulic switch controlled.

Provides infinite variations of 4 main steering modes: front only, rear only, crab and coordinated.

Rear steer indicator.

Turning radius: 7,3 m (24 ft)

-	Axles	

Front: Drive/steer with differential and planetary reduction hubs rigid mounted to frame.

Rear: Drive/steer with differential and planetary reduction hubs pivot mounted to frame.

#### Oscillation lockouts

**Brakes** 

Automatic full hydraulic lockouts on rear axle permits 25,4 cm (10 in) oscillation only with boom centered over the front.

### O

Full hydraulic split circuit operating on all wheels. Spring-applied, hydraulically released parking brake mounted on front axle.




Standard 29.5 x 25 - 34 bias ply, Titan

#### Lights

Full lighting including turn indicators, head, tail, brake and hazard warning lights.

#### Maximum speed

35 km/h (22 mph)



75%

(Based on 52 607 kg [115,976 lb] GVW, 29.5 x 25 tires, 43,2 m [142 ft] boom, plus 17,0 m [56 ft] swingaway, 22,000 lb counterweight, 80 t [90 USt] hookblock and 9,1 t [10 USt] headache ball).

#### Miscellaneous standard equipment

Full width steel fenders, full length aluminum decking, dual rear view mirrors, hook-block tie down, electronic back-up alarm, light package, front stowage well, cab air conditioning, tachometer/hourmeter, rear wheel position indicator, 36,000 BTU hot water cab heater, hoist mirrors, engine distress A/V warning system, front/rear tie down and tow lugs, coolant sight level indicator, CraneSTAR asset management system.

#### \*Optional equipment

- Auxiliary Lighting and Convenience Package: includes cab mounted amber flashing light, dual base boom mounted floodlights. LMI light bar (in cab), and rubber mat for stowage trough
- 360° NYC style mechanical swing lock
- Rear Pintle hook
- Cab controlled cross axle differential locks, (front and rear)
- PAT event recorder
- 3rd wrap indicator for main and/or auxiliary hoists
- Wind speed indicator (wireless).
- C.E. Mark Conformance
- Value Package: Includes 33 ft 56 ft manual bi-fold swingaway, 360° swing lock, and auxiliary hoist package
- 29<sup>C</sup>/-20<sup>F</sup> Cold Weather Package
- 40<sup>C</sup>/-40<sup>F</sup> Arctic Weather Package
- Spare Tire and Wheel

5767 (supersedes 5721)-0117-N4



2

### **Operator's Cab and Controls**

Environmental Cab - Fully enclosed, one person cab of galvaneal steel structure with acoustical insulation Equipped with:

- · Tinted and tempered glass windows
- · Extra-large fixed front window with windshield wiper and washer
- · Swing up roof window with windshield wiper and washer
- Sliding left side door with large fixed window
- Sliding rear and right side windows for ventilation
- · Six way adjustable, cushioned seat with seat belt and storage compartment
- · Diesel fired warm-water heater with air ducts for front windshield defroster and cab floor
- Defroster fan for the front window
- Bubble level
- Circulating fan
- Adjustable sun visor
- Dome light
- Cup holder
- Fire extinguisher
- · Left side viewing mirror
- Two position travel swing lock
- AM/FM radio

Air Conditioning - Optional - Integral with cab heating system utilizing the same ventilation outlets

Engine Dependant Warm-Water Heater - Optional -With air ducts for front windshield defroster and cab floor Steering Column - Pedestal type with tilt and telescope functions for operator comfort. Column includes the

following controls and indicators:

- Left and right levers include:
- Horn button
- Turn signal switch
- · Driving light switch
- Transmission direction switch Panel mounted switches for:
- · Travel park brake
- · Steer mode selector
- 2/4 wheel drive/range selector

- Transmission gear selector
- Hazard flasher
- Panel mounted indicator/warning lights for:
- Transmission temperature
- Service brake
- Turn signals
- · Rear wheel offset
- Emergency steer optional
- Armrest Controls Two dual axis hydraulic joystick
- controllers or optional single axis hydraulic controllers for: Cab heater and A/C Controls
- Swina
- Boom hoist
- Main rear winch
- Auxiliary front winch optional
- Drum rotation indication
- · Drum rotation indicator activation switch
- Winch high/low speed and disable switch(es)
- Warning horn button
- Swing park brake
- Engine throttle lock

Outrigger Controls – Hand held control box with umbilical cord gives the operator the freedom to view operation while setting the outriggers.

#### **Foot Controls**

- · Boom telescope
- · Swing brake
- · Engine throttle
- Service brake


#### Right Front Console - Controls and indicators for:

- Engine ignition
- Engine throttle lock
- Function disable
- Front windshield wiper
- and washer
- Cab floodlights
- Warning horn
- Console dimmer switch
- Bubble level
- · Ignition switch on indicator liaht
  - Boom floodlight's optional
  - Rotating beacon/Strobe light - optional
  - Third wrap set and activate switches - optional
- 12 volt power connections • E-stop switch



## Working range









Dimensions are for largest Grove furnished hook block and headache ball, with anti-two block activated.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



## Mode A vs. Mode B

Mode A – inner-mid retracted											
		Main boom length in feet									
	37.3	50.4	63.4	76.4	89.4	102.4	115.4	141.7			
Boom sections	5:			Perc	ent exten	sion					
Inner-mid	0	0	0	0	0	0	0	100			
Center-mid	0	50	100	100	100	100	100	100			
Outer-mid	0	0	0	25	50	75	100	100			
Fly	0	0	0	25	50	75	100	100			

			Mode	B – norma	al mode							
		Main boom length in feet										
	37.3	50.5	63.7	76.7	89.8	102.8	115.8	128.8	141.7			
Boom sections: Percent extension												
Inner-mid	0	50	75	75	100	100	100	100	100			
Center-mid	0	0	25	75	100	100	100	100	100			
Outer-mid	0	0	0	0	0	25	50	75	100			
Fly	0	0	0	0	0	25	50	75	100			



oad	charts
And n D)	

(Mode B)

37.3 ft - 141	.7 ft 22,00		D00% spread	<b>Q</b> 360°					
		•	•		Pounds				
Feet	37.3	50.5	63.7	Main bo 76.7	oom length in f 89.8	eet 102.8	115.8	128.8	141.7
10	180,000 (68.5)	134,000 (75)	*97,500 (78)			10210			
12	156,000 (65)	134,000 (72.5)	97,500 (76.5)						
15	128,500 (59.5)	127,500 (69)	97,500 (74)	69,950 (77)	*46,600 (78)				
20	98,650	97,600	86,200	63,600	46,600	*38,700			
25	(49.5) 78,800	(62.5) 77,800	(69) 74,850	(73)	(76.5) 41,950	(78) 38,700	*37,900	*30,850	
30	(36.5) 51,550	(55.5) 58,700	(64) 59,300	(69) 48,150	(73) 37,350	(75.5) 37,900	(78) 35,000	(78) 30,850	*24,400
35	(12.5)	(47.5) 43,250	(58.5) 43,200	(65) 42,450	(69.5) 33,300	(72.5) 33,200	(75) 30,950	(77.5) 28,900	(78) 24,400
40		(38.5) 33,250	(52.5) 32,850	(60.5) 33,050	(66) 29,850	(69.5) 29,300	(72.5) 27,450	(75) 25,850	(77) 24,250
40		(26)	(46.5) 25,650	(56) 26,000	(62.5) 25,900	(66.5) 25,950	(70) 24,450	(72.5) 23,150	(75) 21,900
50			(39) 20,350	(51) 20,750	(58.5) 20,550	(63.5) 21,950	(67) 21,800	(70) 20,750	(73) 19,800
			(30.5) 16,200	(45.5) 16,800	(54.5) 16,450	(60) 17,800	(64.5) 19,150	(67.5) 18,650	(70.5) 17,900
55			(16.5)	(39.5) 13.600	(50) 13,200	(56.5) 14,550	(61.5) 15.900	(65) 16,800	(68.5) 16,150
60				(33) 11,000	(45.5)	(53) 11,900	(58.5) 13.250	(62.5) 14.200	(66) 14,650
65				(23.5)	(40.5) 8420	(49) 9750	(55.5)	(60)	(64)
70					(34.5)	(45)	(52)	(57)	(61.5)
75					6570 (28)	7910 (40.5)	(48.5)	10,100 (54.5)	(59)
80					4960 (18)	6340 (36)	7670 (45)	8530 (51.5)	9380 (56.5)
85						4990 (30)	6320 (41)	7150 (48.5)	7980 (54)
90						3780 (23)	5140 (37)	5950 (45)	6770 (51)
95						2710 (10)	4100 (32)	4900 (41.5)	5700 (48.5)
100							3160 (26)	3960 (37.5)	4750 (45.5)
105							2310 (18.5)	3130 (33.5)	3910 (42)
110								2370 (28.5)	3150 (38.5)
115								1680 (22.5)	2460 (35)
120								1050 (13)	1840 (30.5)
125								(13)	1250 (25.5)
Ainimum bo	om angle (deg)	for indicated le	ngth (no load)					0	24
#LMI operati *This capacit	oom length (ft) a ng code. Refer t y is based upon m angles are in o	o LMI manual fo maximum obta	or instructions	igle.				128	3.8
Reem		L	ifting capacitie		e boom angle om length in fee	at .			
Boom angle	37.3	50.5	63.7	76.7	89.8	102.8	115.8		
	27 500	15 050	0560	F040	272.0	1010	1200		

Boom		Main boom length in feet									
angle	37.3	50.5	63.7	76.7	89.8	102.8	115.8				
0°	27,500 (30.1)	15,950 (43.3)	9560 (56.4)	5840 (69.5)	2730 (82.6)	1910 (95.6)	1200 (108.5)				
Note: ( ) Refer	rence radii in fee	et.						A6-829-103321A			

## Load charts

Bi-fold swingaway (fixed offsettable angles)

37.3 ft - 141.7 ft	33 ft -	56 ft	22,000		100% ft spread	Q 360°
			Pour	nds		
	3	3 ft LENGTH	1		56 ft LENGTI	4
()	0° OFFSET	20° OFFSET	40° OFFSET	0° OFFSET	20° OFFSET	40° OFFSET
Feet	#0021	#0022	#0023	#0041	#0042	#0043
40	13,700 (78)					
45	13,700 (76.5)	*13,000 (78)		7160 (78)		
50	13,700 (75)	12,950 (77.5)		7160 (77.5)		
55	13,700 (73)	12,600 (76)	*10,250 (78)	7160 (76)		
60	13,700 (71.5)	12,200 (74)	10,050 (77)	7160 (74.5)	*6400 (78)	
65	13,700 (69.5)	(74) 11,900 (72.5)	9900 (75)	7160 (73)	6250 (77.5)	
70	13,500	11,550	9750	7160	6110	
75	(68) 12,400	(70.5)	(73) 9610	(71.5) 7160	(76) 5980	°5110
80	(66) 10,800	(68.5) 11,000	(71) 9480	(70) 7160	(74.5) 5850	(78) 5020
85	(64) 9330	(67) 10,250	(69) 9370	(68.5) 7150	(73) 5730	(77) 4930
	(62) 8050	(65) 8900	(67) 8980	(66.5) 6960	(71.5) 5620	(75) 4850
90	(60) 6920	(63) 7700	(65) 8530	(65) 6770	(69.5) 5510	(73.5) 4780
95	(58)	(61)	(63)	(63.5)	(68)	(71.5)
100	5920 (56)	6630 (59)	7360 (61)	6590 (61.5)	5410 (66)	4710 (69.5)
105	5030 (54)	5690 (56.5)	6310 (58.5)	6030 (60)	5310 (64.5)	4650 (68)
110	4230 (52)	4830 (54.5)	5370 (56.5)	5200 (58)	5220 (62.5)	4600 (66)
115	3510 (49.5)	4060 (52)	4520 (54)	4450 (56.5)	5110 (60.5)	4550 (64)
120	2850 (47.5)	3360 (50)	3750 (51.5)	3770 (54.5)	4780 (59)	4500 (62)
125	2250 (45)	2730 (47.5)	3040 (49)	3150 (52.5)	4080 (57)	4460 (60)
130	1700 (42)	2150 (44.5)	2400 (46)	2580 (50.5)	3450 (55)	3970 (58)
135	1200	1610 (42)	(40)	2060	2870	3330
140	(39.5)	1120		(48.5)	(53) 2330	(55.5) 2730
145		(39)		(46.5) 1130	(50.5) 1830	(53) 2180
150				(44)	(48.5) 1370	(50.5) 1670
					(46)	(48) 1200
155 Minimum boom angle						(45)
(°) for indicated length (no load)	38	38	40	43	44	44
Maximum boom length (ft) at 0° boom angle (no load)		102.8			89.8	
NOTE: ( ) Boom angles a	e in degrees.				AG	-829-103447

NOTE: () Boom angles are in degrees. An #LMI operating code. Refer to LMI manual for operating instructions.

\*This capacity is based upon maximum boom angle.


#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 3<sup>3</sup> ft extension length may be used with single or double part line lifting service. The 56 ft extension length may be used for single line lifting service only.
- 3. For main boom lengths less than 14.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- 4. WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- 6. Capacities listed are with outriggers properly extended and vertical jacks set only.
- 7. When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17.3 ft spread).



## Working range

#### 141.7 ft main boom and one 16 ft insert




Operating radius in feet from axis of rotation



Dimensions are for largest Grove furnished hook block and headache ball, with anti-two block activated.

# Working range

#### 141.7 ft main boom and two 16 ft inserts



Operating radius in feet from axis of rotation



Dimensions are for largest Grove furnished hook block and headache ball, with anti-two block activated.



### **Load charts** Bi-fold swingaway with inserts (fixed angles)

37.3 ft - 141.7 f	t 33 ft - !		or 2 16 ft inserts	22,000 II	0 1009 24 ft spi	
			Pou	nds		
Feet 7	#0064	ENGTH + 20° OFFSET #0065	1 INSERT) 40° OFFSET #0066	88 ft (56 ft O° OFFSET #0084	LENGTH + 20° OFFSET #0085	40°
50	6300 (78)					
55	6300 (77.5)					
60	6300 (76.5)			5000 (78)		
65	6300 (75)			5000 (77.5)		
70	6300 (73.5)	*6100 (78)		5000 (76)		
75	6,00 (72)	5860 (77.5)		5000 (74.5)	*4900 (78)	
80	6300 (70.5)	5750 (76)	*5000 (78)	5000 (73.5)	4900 (77.5)	
85	6300 (69)	5650 (74.5)	4890 (77.5)	5000 (72)	4900 (76)	
90	6300 (67.5)	5550 (73)	4820 (76)	4900 (70.5)	4900 (74.5)	*4800 (78)
95	6300 (66)	5450 (71.5)	4760 (74.5)	4850 (69.5)	4900 (73.5)	4640 (76.5)
100	6300 (64.5)	5360 (70)	4690 (73)	4800 (68)	4710 (72)	4370 (75)
105	5810 (63)	5120 (68)	4580 (71.5)	4670 (66.5)	4420 (70.5)	4120 (73.5)
110	5030 (61.5)	4880 (66.5)	4480 (69.5)	4550 (65)	4130 (69)	3870 (72)
115	4320 (59.5)	4620 (65)	4270 (68)	4240 (63.5)	3880 (67.5)	3650 (70.5)
120	3680 (58)	4370 (63.5)	4060 (66)	3850 (62)	3630 (66)	3440 (69)
125	3100 (56.5)	4110 (61.5)	3870 (64.5)	3260 (60.5)	3410 (64.5)	3240 (67.5)
130	2560 (54.5)	3500 (60)	3680 (62.5)	2720 (59)	3190 (63)	3050 (65.5)
135	2070 (53)	2940 (58)	3510 (60.5)	2220 (57.5)	3000 (61.5)	2880 (64)
140	1610 (51)	2420 (56)	2980 (58.5)	1760 (56)	2630 (60)	2710 (62.5)
145	1190 (49)	1950 (54.5)	2440 (56.5)	1340 (54.5)	2,150 (58)	2560 (60.5)
150		1500 (52.5)	1930 (54.5)		1700 (56.5)	2210 (58.5)
155		1090 (50.5)	1470 (52)		1290 (54.5)	1750 (57)
160			1030 (50)			1310 (55)
Minimum boc (°) for indicate length (no loa	d)	49	49	52		53
Maximum boo (ft) at 0° boon (no load)	n angle	76.7			76.7	

NOTE: ( ) Boom angles are in degrees. A6-829-103478 #LMI operating code. Refer to LMI manual for operating instructions. "This capacity is based upon maximum boom angle.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- 2. The 56 ft extension length may be used for single line lifting service only.
- 3. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- 4. WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- When lifting over the main boom nose with 56 ft extension erected and inserts, the outriggers must be fully extended and vertical jacks set.



### Load charts (Mode A)

37.3 ft - 141.7	ft 22,000 lb	100% 24 ft sprea	Q 360°					
				Po	unds			
Feet	37.3	50.4	63.4	76.4	89.4	102.4	115.4	141.7
10	180,000 (68.5)	134,000 (75)	*80,800 (78)					
12	156,000 (65)	134,000 (72.5)	80,800 (76.5)	*38,700 (78)				
15	128,500 (59.5)	129,000 (68.5)	80,800 (73.5)	38,700 (77)	*38,500 (78)			
20	98,650 (49.5)	98,950 (62)	70,950 (68.5)	38,700 (73)	38,500 (76.5)	*38,400 (78)		
25	78,800 (36.5)	79,150 (55)	62,300 (63.5)	38,700 (69)	38,500 (73)	38,400 (76)	24,400 (78)	
30	51,550 (12.5)	60,500 (47)	55,250 (58)	38,700 (65)	38,500 (69.5)	37,500 (73)	24,400 (76)	*24,400 (78)
35		45,150 (38)	44,900 (52.5)	38,700 (60.5)	36,750 (66)	33,150 (70)	24,400 (73.5)	24,400 (77)
40		35,250 (25.5)	34,700 (46)	36,750 (56)	32,750 (62)	29,550 (67)	24,400 (70.5)	24,250 (75)
45		(23.3)	27,600 (39)	29,450 (51)	29,400 (58.5)	26,500 (63.5)	24,400 (68)	21,900 (73)
50			22,400 (30)	24,000 (45.5)	25,650 (54.5)	23,950 (60.5)	22,050 (65)	19,800 (70.5)
55			18,250 (15.5)	19,850 (39.5)	21,350 (50)	21,750 (57)	20,000 (62)	17,900 (68.5)
60			(15.5)	16,600 (32.5)	17,950 (45.5)	18,900 (53.5)	18,250 (59)	16,150 (66)
65				13,850 (23)	15,200 (40)	16,150 (49.5)	16,700 (56)	14,650 (64)
70				(23)	12,950 (34.5)	13,850 (45.5)	14,800 (53)	12,850 (61.5)
75					11,000 (27.5)	11,950 (41)	12,900 (49.5)	10,950 (59)
80					9340 (17)	10,300	11,250	9380
85					(17)	(36) 8900 (30)	(45.5) 9830 (42)	(56.5) 7980 (54)
90						7640	8590	6770
95						(22.5) 6520	(37.5) 7510	(51) 5700
100						(8)	(32.5) 6520	(48.5) 4750
105							(26.5) 5640	(45.5) 3910
110							(18.5)	(42) 3150
115								(38.5) 2460
120								(35) 1840
125								(30.5) 1250
linimum boon laximum boor LMI operating This capacity i	n angle (deg) for in n length (ft) at 0 de code. Refer to LM s based upon maxi angles are in degre	eg boom angle (I I manual for inst imum obtainable	no load)					(25.5) 24 115.4
			acities at zero d					
Boom angle	37.3	50.4	63.4	1ain boom lengt 76.4	h in feet 89.4	102.4	115.4	
0°	27,500 (30.1)	17,300 (43.2)	11,050 (56.2)	8580 (69.2)	6700 (82.2)	5380 (95.2)	4280 (108.2)	

Note: ( ) Reference radii in feet.

6-829-103320A



Load (Mode A		arts		
37.3 ft - 76.4	ft 22,0	<b>00 Ib</b>	() Stationary	<b>Q</b> 360°
		F F	Pounds	
Ģ			boom	
Feet	37.3	Main boom 50.4	length in feet 63.4	t 76.4
12	39,500	41,650	03.4	/0.4
	(65) 37.750	(72.5) 38.950	18.900	15.650
15	(59.5)	(68.5)	(73.5)	(77)
20	24,850 (49.5)	24,850 (62)	18,900 (68.5)	15,650 (73)
25	16,300 (36,5)	16,650 (55)	17,450 (63,5)	15,650 (69)
30	10,200 (12.5)	11,350 (47)	11,450 (58)	13,200 (65)
35	(12.3)	7650	7630	9280
40		(38) 4920	(52.5) 5020	(60.5) 6510
		(25.5)	(46)	(56) 4490
45				(51)
Minimum indicate	l boom angle d length (no le	(°) for bad)	39	46
Maximum b	oom length (f angle (no loa	t) at 0° d)	50	.4
	5.		ree boom angle	e
Boom angle	37.3	Jain boom len 50.4	igth in feet	
0°	10,050 (30.1)	3150 (43.2)		
NOTE: () Refe			A	6-829-103452A

			ω	Q
37.3 ft - 76.4	ft 22,00		c and carry to 2.5 mph	Boom centered over front
			Pounds	
			in boom	
Ø		Main boo	n length in f	eet
Feet	37.3	50.4	63.4	76.4
12	41,600 (65)	41,700 (72.5)		
15	41,600 (59.5)	41,700 (68.5)	22,400 (73.5)	15,650 (77)
20	36,250 (49.5)	36,450 (62)	22,400 (68.5)	15,650 (73)
25	27,600 (36.5)	28,250 (55)	22,400 (63.5)	15,650 (69)
30	21,300 (12.5)	22,200 (47)	22,400 (58)	15,650 (65)
35		17,500 (38)	17,950 (52.5)	15,650 (60.5)
40		13,800 (25.5)	14,350 (46)	15,650 (56)
45			11,000 (39)	12,500 (51)
50			8360 (30)	9820 (45.5)
55			6240 (15.5)	7690 (39.5)
Minimum l	ooom angle (°) (no	for indicated l load)	ength	36
Maximum	boom length ( (no	ft) at 0° boom load)	angle	63.4
Lifting	capacities at z	ero degree boo	om angle	
Boom angle	37.3	Main boom ler 50.4	gth in feet 63.4	
0°	21,150 (30,1)	11,600 (43.2)	5790 (56.2)	
				AC 820 102452

#LMI operating code. Refer to LMI manual for instructions.

#### NOTES:

- 1. Capacities are in pounds and do not exceed 75% of tipping loads as determined by test in accordance with SAE J765.
- 2. Capacities are applicable to machines equipped with 29.5x25 (34 ply) General tires at 76 psi cold inflation pressure.
- 3. Capacities appearing above the bold line are based on structural strength and tipping should not be relied upon as a capacity limitation.
- 4. Capacities are applicable only with machine on firm level surface.
- 5. On rubber lifting with boom extensions not permitted.

#LMI operating code. Refer to LMI manual for instructions.

- 6. For pick and carry operation, boom must be centered over front of machine, mechanical swing lock engaged and load restrained from swinging. When handling loads in the structural range with capacities close to maximum ratings, travel should be reduced to creep speeds.
- 7. Axle lockouts must be functioning when lifting on rubber.
- 8. All lifting depends on proper tire inflation, capacity and condition. Capacities must be reduced for lower tire inflation pressures. See lifting capacity chart for tire used. Damaged tires are hazardous to safe operation of crane.
- 9. Creep not over 200 ft of movement in any 30 minute period and not exceeding 1 mph.

#### **CURRAN** CI'ANE IT'S NOT LUCK, IT'S KNOW HOW "

### 33 ft – 56 ft luffing bi-fold boom extension (Mode B) (fixed offsettable angles)

<b></b>	33 ft - 5	)	2,000 lb		00% spread	<b>Q</b> 360°
		Pounds				
		t LENGT			5 ft LENG	
Feet	#0091	20° OFFSET #0091	40° OFFSET #0091	5° OFFSET #0092	20° OFFSET #0092	40° OFFSET #0092
40	*13,700 (78)					
45	13,700 (77)					
50	13,700 (75)	13,700 (77.5)		*8200 (78)		
55	13,700 (73.5)	13,700 (75.5)	*11,000 (78)	8200 (77.5)		
60	13,700 (71.5)	13,700 (74)	11,000 (76)	8200 (76)		
65	13,700 (70)	12,850 (72)	10,950 (74.5)	8200 (74.5)	8200 (77.5)	
70	12,500 (68)	12,000 (70)	10,350 (72.5)	8200 (73)	8200 (76)	
75	11,350 (66)	11,200 (68)	9830 (70.5)	8200 (71.5)	8100 (74)	6400 (77.5)
80	9730 (64.5)	10,450 (66.5)	9330 (68.5)	8200 (69.5)	7600 (72.5)	6400 (76)
85	8300 (62.5)	8980 (64.5)	8860 (66.5)	8200 (68)	7150 (71)	6230 (74)
90	7060 (60.5)	7660 (62.5)	8210 (64.5)	7740 (66.5)	6730 (69)	5920 (72.5)
95	5960 (58,5)	6500 (60,5)	6980 (62)	7130 (64.5)	6350 (67.5)	5640 (70.5)
100	4990 (56.5)	5470 (58)	5880 (60)	6130 (63)	6000 (65.5)	5380 (68.5)
105	4120 (54)	4560 (56)	4900 (58)	5230 (61)	5690 (64)	5140 (67)
110	3340 (52)	3730 (54)	4020	4430 (59,5)	5290 (62)	4900 (65)
115	2640 (49.5)	2990 (51.5)	3230 (53)	3700	4490 (60)	4690 (63)
120	2000 (47.5)	2320 (49)	2510 (50.5)	3040 (55.5)	3760 (58.5)	4470 (61)
125	1420 (45)	1700 (46.5)	1850 (47.5)	2440 (53.5)	3100 (56.5)	3710 (58.5)
130	(15)	1140 (44)	1250 (45)	1900 (51.5)	2500 (54.5)	3030 (56.5)
135		()	(,	1390 (49.5)	1940 (52)	2390 (54)
140				(15.5)	1420 (50)	1810 (52)
145					(30)	1270 (49)
Minimum boom (°) for indicated length (no load)	42	43	43	48	48	47
Maximum boom (ft) at 0° boom a (no load)	ı length	89.8			76.7	
NOTE: ( ) Boom a	ingles are	in degree	25.		A6-82	9-103522

#LMI operating code. Refer to LMI manual for operating instructions. \*This capacity is based upon maximum boom angle.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 33 ft luffing folding boom extension may be used for single or double line lifting service. The 56 ft luffing folding boom extension may be used for single line lifting service only.
   WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, is strictly prohibited.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- 5. Capacities listed are with outriggers properly extended and vertical jacks set only.
- 6. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17.3 ft spread).



### 33 ft – 56 ft luffing bi-fold boom extension (Mode B) (intermediate offsettable angles)

37.3 ft - 141.7	/ft 33 ft - !	56 ft 22,000 ll	b 100% 24 ft spr	G 360° read
		Pou	nds	
	•	ENGTH	-	LENGTH
Feet	5° - 20° OFFSET #0	20° - 40° OFFSET 091	5° - 20° OFFSET #0	20° - 40° OFFSET 092
50	11,850			
55	11,550	10,750		
60	11,200	10,600		
65	10,900	10,450	6150	
70	10,650	10,350	5960	
75	10,350	9830	5780	5370
80	9730	9330	5610	5280
85	8300	8860	5450	5200
90	7060	7660	5310	5130
95	5960	6500	5170	5070
100	4990	5470	5040	5010
105	4120	4560	4920	4910
110	3340	3730	4430	4810
115	2640	2990	3700	4490
120	2000	2320	3040	3760
125	1420	1700	2440	3100
130		1140	1900	2500
135			1390	1940
140				1420
Min. boom angle for indicated length (no load)	43°	43°	48°	48°
Max. boom length at 5° boom angle (no load)	89.	8'	76.	7

#LMI operating code. Refer to LMI manual for A6-829-103525A operating instructions.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 33 ft luffing folding boom extension may be used for single or double line lifting service. The 56 ft luffing folding boom extension may be used for single line lifting service only.

WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, is strictly prohibited.

- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- The loads for luffing depend on the angle of the main boom, angle of the boom extension and dynamic working pressure of the luffing cylinder for the boom extension.
- Capacities listed are with outriggers properly extended and vertical jacks set only.
- When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17.3 ft spread).



### 33 ft - 56 ft luffing bifold boom extension with inserts (Mode B) (intermediate offsettable angles)

		-	Poune		1 ft sprea	ıd
	A. 150 A. 15					-
<u></u>	ft (56 ft LE 2° 5°	20°	40°	5°	t LENGTH + 20°	40°
Feet	OFFSET #0095	OFFSET #0095	OFFSET #0095	OFFSET #1095	OFFSET #1095	OFFSE1 #1095
55	*6400 (78)					
60	6400 (77.5)					
65	6400 (76)			*5000 (78)		
70	6400 (74.5)	*6400 (78)		5000 (77)		
75	6400 (73.5)	6400 (76.5)		5000 (75.5)	*5000 (78)	
80	6400 (72)	6400 (75)	*5500 (78)	5000 (74.5)	5000 (76)	
85	6400 (70.5)	6040 (73.5)	5420 (76)	5000 (73)	5000 (74.5)	*4460 (78)
90	6250 (69)	5630 (72)	5100 (74.5)	5000 (71.5)	4790 (73)	4460 (76.5)
95	5800 (67.5)	5260 (70.5)	4800 (73)	4740 (70)	4420 (71.5)	4150 (75)
100	5380 (66)	4910 (69)	4520 (71.5)	4350 (69)	4090 (70.5)	3860 (73.5)
105	5010 (64)	4610 (67.5)	4270 (69.5)	4010 (67.5)	3790 (69)	3600 (72)
110	4570 (62.5)	4310 (65.5)	4020 (68)	3680 (66)	3490 (67.5)	3340 (70.5)
115	3840 (61)	4040 (64)	3790 (66)	3390 (64.5)	3230 (66)	3110 (69)
120	3180 (59.5)	3780 (62.5)	3570 (64.5)	3110 (63)	2980 (64.5)	2890 (67.5)
125	2570 (57.5)	3290 (60.5)	3370 (62.5)	2720 (61.5)	2760 (63)	2680 (66)
130	2020 (56)	2680 (59)	3180 (60.5)	2160 (60)	2540 (61.5)	2480 (64.5
135	1510 (54)	2120 (57)	2680 (59)	1640 (58.5)	2300 (59.5)	2300 (62.5)
140	1040 (52.5)	1600 (55)	2100 (57)	1170 (57)	1780 (58)	2120 (61)
145		1130 (53)	1560 (54.5)	. ,	1300 (56.5)	1820 (59)
150			1060 (52.5)		. ,	1320 (57)
Minimum boo (°) for indicated length (no load	1 51 1)	52	51	56	55	56
Maximum boo (ft) at 0° boom (no load)	m length 1 angle	76.7			63.7	

NOTE: () Boom angles are in degrees. A6-829-10352: #LMI operating code. Refer to LMI manual for operating instructions. "This capacity is based upon maximum boom angle.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 56 ft luffing folding boom extension may be used for single line lifting service only.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- 4. WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, or with either one or two 16 ft insert sections installed, is strictly prohibited.
- 5. For main boom lengths less than 141.7 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.
- When lifting over the main boom nose with the 56 ft extension erected and inserts, the outriggers must be fully extended and vertical jacks set.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. Grove RT890E The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



### 33 ft – 56 ft luffing bi-fold boom extension with inserts (Mode B) (intermediate offsettable angles)

<b>37.3 ft - 141.7 f</b> t		1 or 2 22, 16 ft inserts		<b>H</b> 00% spread
(		Poun	ıds	
Feet	2 ft LENGTH (5 5° - 20° OFFSET #009	6 ft + 1 INSERT) 20° - 40° OFFSET 95	5° - 20°	56 ft + 2 INSERTS) 20° - 40° OFFSET 095
70	6090			
75	5920		5000	
80	5750	5340	5000	
85	5600	5260	5000	4460
90	5460	5100	4790	4460
95	5260	4800	4420	4150
100	4910	4520	4090	3860
105	4610	4270	3790	3600
110	4310	4020	3490	3340
115	3840	3790	3230	3110
120	3180	3570	2980	2890
125	2570	3290	2720	2680
130	2020	2680	2160	2480
135	1510	2120	1640	2300
140	1040	1600	1170	1780
145		1130		1300
Min. boom angle for indicated length (no load)	52°	52°	56°	56°
Max. boom length at 5° boom angle (no load)	76.7'		63.	7' A6-829-103526

#LMI operating code. Refer to LMI manual for operating instructions.

#### NOTES:

- All capacities above the bold line are based on structural strength of boom extension and do not exceed 85% of tipping loads, in accordance with SAE J-765.
- The 56 ft luffing folding boom extension may be used for single line lifting service only WARNING: Lifting with the 33 ft extension base, with the 23 ft extension fly either erected or folded along side of extension base, or with either one or two 16 ft insert sections installed, is strictly prohibited.
- WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.
- The loads for luffing depend on the angle of the main boom, angle of the boom extension and dynamic working pressure of the luffing cylinder for the boom extension.
- When lifting over the main boom nose with 56 ft extension erected and inserts, the outriggers must be fully extended and vertical jacks set only.



## Load handling


Weight reductions for load	handling devices
33 ft – 56 ft Folding boom exte	nsion
*33 ft extension (erected)	3750 lb
*56 ft extension (erected)	8000 lb
*72 ft (1 insert erected)	10,450 lb
*88 ft (2 inserts erected)	13,000 lb
*Reduction of main boor	n capacities
(no deduct required for stowed	l boom extension)
Auxiliary boom nose	133 lb
Hookblocks and headache balls:	
80 USt, 5 sheave	1600 lb +
90 USt, 5 sheave	1300 lb +
10 LICE succession of the U	ECO III

10 USt overhaul ball 568 lb + + Refer to rating plate for actual weight.

When lifting over swingaway and/or jib combinations, deduct total weight of all load handling devices reeved over main boom nose directly from swingaway or jib capacity.

<u>NOTE</u>: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Grove furnished equipment.

Line pulls and reeving information						
Hoists	Cable specs	Permissible line pulls	Nominal cable length			
Main	19 mm (3/4 in) 6x37 class, EIPS, IWRC special flexible min. breaking str. 58,800 lb		600 ft			
	19 mm (3/4 in) Flex-X 35 I Aux. rotation resistant (non-rotating) nin. breaking strength 85,800	16,800 lb ) lb	600 ft			
The a	approximate weight of 3/4 in v	wire rope is	1.5 lb/ft			




#### Installation and removal of counterweight and auxiliary hoist

Rated lifting capacities in pounds on outriggers fully extended –

Radius in feet	LMI Code #0801 Main boom length 37.3 ft°
10	24,000
12	24,000
15	24,000
20	24,000
25	24,000
30	24,000
*The boo	om must be fully retracted.
	A6-829-103450

Hoist performance							
Wire rope layer	two spe Low	Hoist line pulls two speed hoist Low High Available lb° Available lb°					
1	20,250	9610	101	101			
2	18,490	8770	110	211			
3	17,010	8070	120	331			
4	15,750	7470	129	460			
5	14,660	6960	139	599			
	*Max. lifting capa	acity: 6x37 or 35x7	class = 16,800	lb			

Working area diagram



Bold lines determine the limiting position of any load for operation within working areas indicated.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. Grove RT890E The individual cranès load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



## Notes







Grove Manitowoc National Crane Potain



### **Manitowoc Cranes**

### **Regional headquarters**

#### Americas

Manitowoc, Wisconsin, USA Tel: +1 920 684 6621 Fax: +1 920 683 6277 Shady Grove, Pennsylvania, USA

Tel: +1 717 597 8121 Fax: +1 717 597 4062

### **Regional offices**

Americas Brazil Alphaville Mexico Monterrey Chile

Santiago

#### Europe, Middle East, Africa Czech Republic Netvorice

France Baudemont Cergy Decines Germany Langenfeld Hungary Budapest Italy Lainate Netherlands Breda Poland Warsaw Portugal Baltar Russia Moscow U.A.E. Dubai U.K. Buckingham

**China** Beijing Chengdu Guangzhou Xian

#### Greater Asia-Pacific Australia

Adetaide Brisbane Melbourne Sydney India Calcutta Chennai Delhi Hyderabad Pune Korea Seoul Philippines Makati City Singapore Brazil Alphaville China TaiAn Zhangjiagang France Charlieu Moulins Germany Wilhelmshaven India Pune Italy Niella Tanaro Portugal Baltar Fânzeres Slovakia Saris USA Manitowoc Port Washington Shady Grove

**Factories** 

Europe, Middle East, Africa

Tel: +33 (0)4 72 18 20 20

Fax: +33 (0)472182000

Ecully, France

**China Shanghai, China** Tel: +86 21 6457 0066 Fax: +86 21 6457 4955

#### Greater Asia-Pacific Singapore

Tel: +65 6264 1188 Fax: +65 6862 4040

This document is non-contractual. Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories and may not include all standard equipment.

©2011 Manitowoc Printed in USA Form No. RT890E PG Part No. 04-008 - 2M -1211

www.manitowoc.com